



TECHNICAL DATA-SHEET



SAUNA
SN 43840



Specifications

BRAND	BELLA
RANGE	PREMIUM
PRODUCT CODE	SN 43840
PRODUCT TYPE	SAUNA
COLOR/FINISH	WOOD
MATERIAL	CANADIAN HEMLOCK WOOD
SIZE (MM)	1200 X 1200 X 1900


*All dimensions are in mm

TECHNICAL DATA-SHEET




Drawing

Scale Unit: mm



*All dimensions are in mm

Instruction Manual



Recommendations

Read this manual carefully before using your sauna for the first time.

We recommend you keep it in a safe place for future reference.

- * Wood is a living element, to maintain its original appearance, it is important to treat the outside of the wood against moisture. Use a saturator only on the outside of the sauna.
- * Install the sauna on a perfectly flat and hard surface.
- * Do not use liquid cleaning products. Disconnect the sauna before cleaning and use a wet rag.
- * Protect the sauna's electrical cable to avoid it being crushed or pinched.
- * Prior to replacing certain components, ensure that they are specified by the manufacturer or that they have the same features as the original parts. Incorrect replacement can cause a fire, a short circuit or damage to the sauna. We strongly recommend using a qualified technician.
- * To avoid the risk of burns or electric shocks, do not use any metal tools.
- * Do not put animals in the sauna.
- * Do not leave the sauna switched on without supervision.
- * Do not leave the sauna switched on for more than 2 hours at a time to avoid premature deterioration of the equipment. After 2 hours continuous usage, switch off the sauna for at least one hour.
- * We recommend that you do not install a locking system on the sauna door.
- * Check compliance of your electrical installation prior to connecting your sauna to the power supply.

Instruction Manual

Safety

IMPORTANT :

Please read the safety instructions carefully before installing and using your sauna cabin.

They are essential for your safety, so please adhere strictly to them.

Beware of hyperthermia, heat stroke or heat exhaustion which can be caused or aggravated by noncompliance with the safety instructions. Symptoms are fever, a rapid pulse, dizziness, fainting, lethargy and numbness in all or part of the body. The effects are: reduced awareness of the heat, ignorance of imminent risks, loss of consciousness.

The sauna must not be used by:

- Children under 6 years of age.
- People with severe reactions to sunlight.
- Elderly or disabled people.
- People with previous medical conditions such as heart disease, high or low blood pressure, blood circulation problems or diabetes without prior medical advice.
- Pregnant women. Excessive temperature can endanger the foetus.
- Persons suffering from dehydration, open sores, eye disorders, burns or sunstroke.

Children between 6 and 16 years of age may use the sauna provided that they are continuously supervised by a responsible adult and that the temperature does not exceed 60°C (140°F).

In the event of problems involving health, medication or injury to muscles or ligaments, do not use the sauna without previously consulting a doctor and obtaining approval.

If surgical implants are worn, do not use the sauna without previously consulting a doctor and obtaining his approval.

Do not use the sauna after strenuous activity.

Wait 30 minutes for your body to cool down.

Do not spend more than 40 minutes in the sauna at any one time.

Do not consume alcohol or drugs before or during the session.

Do not sleep in the sauna when it is in operation.

To avoid the risk of overheating, connect your sauna to a sufficiently powerful electrical outlet and do not connect other electrical equipment to the same wall socket.

To avoid any risk of electrocution or damage to the sauna, do not use it:

- During thunderstorms.
- If the electrical cable is damaged, it must be replaced by a qualified person.
- If the electrical cable overheats, it must be checked by a qualified person.
- If you have to change a bulb, wait until the sauna is switched off and cooled down.

Dry your hands before connecting or disconnecting the electricity.

Never work with wet hands or feet.

Do not switch the electricity or the heating system rapidly on or off as this could damage the electrical system.

Do not try to repair the sauna by yourself without the agreement of the sauna's distributor or manufacturer.

Unauthorized attempts to repair it will invalidate the manufacturer's warranty.

Do not use any type of detergent inside the sauna.


Do not pile up or store objects inside or on top of the sauna.

Do not place flammable materials or chemical agents near the sauna.

TECHNICAL DATA-SHEET

Instruction Manual

Description sauna



1	Duster cover	7	Sauna stove	13	Back board(Left)	19	Bottom board
2	Top panel	8	Hinge	14	Back board(Right)		
3	Right panel	9	Heater wooden frame	15	Window glass(2)		
4	Backrest	10	Door glass	16	Seat board support frame		
5	Upper bench	11	Handle	17	Bench		
6	Under bench support	12	Window glass(1)	18	Bench support		

Note: For other models in this series (with different sizes but similar product configurations), this schematic diagram can be referred to.

Instruction Manual

Read the assembly instructions carefully before starting.

Choice of location

Select a space:

- In a dry area, on a flat stable surface that can support the weight of your sauna.
- The height must be sufficient for you to reach the ceiling and carry out electrical connections and maintenance.
- Away from any source of water, flames or flammable materials.

Practical advice

- Note that sauna assembly requires 3 adults.
- Clearly identify each panel before you begin
- During assembly, position your sauna's mains cable so that it is easily accessible.
- Note that there are variations between the models.

Tools needed



Screwdriver




Tape measure



Pencil




Cutter




Electric
screwdriver



Allen Wrench



Step ladder




Mallet


Instruction Manual

Assemble instructions

Please first install the external structure of the sauna ,
and then install the interior trim once it is stable.



→ Take out the base plate and place it
on a flat ground for installation







Take out the rear panel and stand it at the corresponding
position behind the base plate

Instruction Manual


Assemble instructions

Assemble steps





Instruction Manual

Assemble steps




Instruction Manual

Assemble steps




Instruction Manual


Assemble steps



Ø 5 x 70 7PCS





Ø 3 x 25 8PCS




Instruction Manual

Assemble steps





Ø 4 x 30 4PCS




Instruction Manual

Assemble steps




Ø 5 x 40 16PCS





Instruction Manual

Assemble steps



Instruction Manual

Assemble steps



For more detailed information on the specific use and precautions of the sauna stove, please read the manual provided with the sauna stove.
Please read the instruction manual of the external controller for the usage of the external controller.


Instruction Manual

Installation precautions

Electrical connection



Every connection cable or plug has a corresponding pair, find male and female with the same label (like “Control”) and plug in correctly.

1.



Connection cable

2.



Connection plug

Make sure connections are tight and secure.

Instruction Manual

Operation

1. Precautions

- a. Check all the circuitry and the plug meet all requirements.
- b. Set the temperature and time to a comfortable level.
- c. Drink a cup of water before the sauna session.
- d. After 2 hours of continuous use, shut the sauna down for one hour.
- e. To avoid burns, do not touch the heating element.
- f. **WARNING:** Covering the heater or infrared emitter causes fire risk!

2. Operation

- a. Plug the sauna into a outlet which is stated in nameplate. Do not share the outlet appliances.
Sauna should be unplugged when not in use (Turn off the cable inlet switch).
- b. After your sauna session, turn off, and unplug the power cable (Turn off the cable inlet switch)
- c. **DO NOT OPERATE THE SAUNA UNSUPERVISED
TO REDUCE THE RISK OF FIRE.**

Note: When the environmental temperature is low, the heating time will take longer. It is also possible the sauna temperature display is not able to reach its maximum temperature. This is normal and does not in any way affect the performance of the infrared heaters or their health benefits. the sauna temperature sensor only measures the heat radiated by the heating elements. It does not measure the infrared heaters penetrating heat and this is where most of the health benefits are.

Instruction Manual

Control panel operation

Color Light Remote Control

Power Control

Turn the light ON or OFF.

RGB Control

Press the color ring to select different colors.

Brightness Control

Adjust the brightness level of the light.

Color-changing speed

When the color-changing mode is active, press to adjust the speed of color transitions.

Color-changing mode

Adjust the light's color-changing function.



Instruction Manual

Maintenance

Before using

1. Please be sure to follow the instruction manual before operations;
2. Prepare a towel on the seat bench to prevent sweat from dripping onto it. To avoid affecting the quality and beauty of wood.

After using

1. Please unplug the power plug in time;
2. Open the door to let the heat and humid water vapor dissipate and keep the sauna cabin dry.

Stain on wood

1. The outer cabin can be wiped with a wrung wet towel; The inner cabin can be wiped by small vacuum cleaner.
2. Do not use organic solvents to decontaminate, such as gasoline, alcohol, etc. wipe the sauna surface;
3. Do not use sharp objects in sauna cabin to prevent scratching woods.

Stain on glass

1. Wipe the glass with soft paper;
2. Stubborn stains can be wiped with a damp cloth, then dry with a dry cloth;
3. Do not scratch the surface with a sharp object to prevent scratching the glass.

Transportation and storage

1. Avoid water, snow and intense impact during the transportation;
2. Do not store it in a humid environment;
3. Some regions have relatively dry climates, often wipe the product with a wrung wet towel;
4. Some regions have relatively humid climates and can be ventilated and dried frequently.